

UG-080  
ギアコンテナ

この度は、スノーピーク製品をお買い上げいただき、誠にありがとうございます。本製品は、キャンプ用品などを収納するためのバッグです。安全にご使用いただくためにも下記の取扱説明書をよく読んでからご使用ください。また、読み終わった後も大切に保管してください。説明内容で理解出来ない点及び製品に不具合が確認された際には直ちに使用を中止し、ご購入いただきました販売店様もしくは弊社ユーザーサービスまでお問い合わせください。

## スベック

- 材質：生地／420Dナイロン(PVC加工)、取っ手／PPテープ、巾着部分／ナイロンメッシュ、底板／ポリエチレン
- サイズ：395×285×310(h)mm
- 重量：820g

**安全上の注意事項** ご使用前によく読んで予測される事故を回避し安全にご使用ください。

**⚠ 注意** ケガや本体破損、物品破損として拡大損害の原因となる行為を示します。

- ご使用前に本製品を点検し、各部に異常がないことを確認してください。異常が発見された場合は、直ちに使用を中止しお問い合わせいただいた販売店様、または弊社ユーザーサービスに点検または修理を依頼してください。
- 火気周辺での放置や、熱いものを入れる行為はお止めください。生地が溶けるなど、破損の原因となるおそれがあります。
- 本製品は防水仕様ではありません。
- 角や先端の鋭いものなどを入れますと生地の破れや穴空きの原因となります。
- 摩擦、水漏れ、雨水、汗の影響によって色落ちや色移りすることがあります。
- 屋外での放置は製品の劣化、退色の原因となります。ご使用後も、直射日光を避けて保管してください。
- 保管の際は高温多湿な場所を避け、通気性の良い場所に保管してください。
- 持ち手を持った状態で製品を引きずらないでください。持ち手や生地の破損・破れ、穴空きの原因となります。
- 生地裏面にPVC加工を施しております。製品内側に湿気がこもる場合がございますので、湿気に弱いものの長期保管は避けてください。
- 持ち運ぶ際には必ず2本のハンドルを束ねて持ってください。ハンドル本体の縫製部に引っ張ると破損するおそれがあります。

## メンテナンスについて

- 長期間ご使用しなかった製品を再度お使いになる際は、本製品を点検し各部に異常がないことを確認してください。異常が発見された場合は、直ちに使用を中止しお問い合わせいただいた販売店様、または弊社ユーザーサービスに点検または修理を依頼してください。
- 本製品は水洗いできません。汚れを落とす際にはよく絞った布などで拭き取ってください。
- 汚れが気になる場合は、水または薄めた中性洗剤を含ませた柔らかい布で軽く拭き取ってください。市販のお掃除シート(アルコール・薬剤を含むもの)は変色や劣化の原因となる場合がありますので使用しないでください。また、シンナーやベンジンなどの溶剤も使用しないでください。
- 汚れを取ったあとは、風通しの良い日陰で十分に乾燥させてください。

## 品質保証について

お問い合わせいただきました製品は万全を期していますが、万一不備な点がございましたら、お問い合わせいただいた販売店様もしくは弊社または各製品に記載された連絡先にご相談ください。製造上の欠陥が原因の場合は無償で修理または交換させていただきます。その他の場合は適切な価格で修理させていただきます。修理、交換の判断は弊社の裁量によるものとさせていただきます。また、以下の場合は修理できない場合もありますので予めご了承ください。

- |                          |                               |
|--------------------------|-------------------------------|
| 1. 素材の経年劣化による損傷など商品の寿命   | 6.ゴミやさびによる故障                  |
| 2. 改造および粗雑な取扱いによる故障      | 7. 分解したことによる不具合の発生または破損       |
| 3. 取扱説明書で禁止されている取扱いによる故障 | 8. 落下やその他の衝撃による部品の変形や破損による不具合 |
| 4. 不測の事故による商品の故障         | 9. 摩擦によるパーツの変化及びそれによる故障       |
| 5. その他製造上の欠陥以外による製品の故障   | 10. 他社製品との組み合わせによる故障          |

## 修理について

- 本格的な修理が必要な場合は、お問い合わせになった販売店様または弊社ユーザーサービスまでお問い合わせください。
  - 修理を依頼される場合は、必ず十分に乾燥させ、汚れをきれいに落としてください。
  - 修理品には修理箇所がはっきりと解るように、必ずメモまたは荷札を付けてください。また破損時の状況をできるだけ詳しく書いたメモを添えてください。
  - 修理品の運賃並びに修理費については以下のように規定させていただきます。
- 1.保証対象の場合：往復運賃並びに修理費は弊社にて負担いたします。  
2.保証対象以外の場合：往復運賃並びに修理費は、お客様の負担とさせていただきます。

## UG-080 Gear Container

Thank you for purchasing a Snow Peak product. This product is a bag for storing camping supplies. For safety, read the following instruction manual before use. Please keep it safe for future reference. Finally, if you find anything that you do not understand in the description or any problems with the product, please stop use immediately and contact the retailer or Snow Peak Customer Service.

### Specifications

●Material: Body / 420D Nylon (PVC), Handle / PP tape, Drawstring Closure / Nylon Mesh, Base Insert / Polyethylene ●Size: 395x285x310(h)mm / 15.5"x11.2"x12.2"(h) ●Weight: 820g / 28.9oz

**Safety Precautions: Before use, please read thoroughly to ensure safety and avoid accidents.**

### CAUTION / Misuse could result in injury to the user and/or damage to property.

- Before using the product, check each part for abnormalities. If there are abnormalities, take the product to the dealer or Snow Peak Customer Service for inspection or repair.
- Do not leave this product near any heat source or put anything hot inside it. It may result in melting the fabric or otherwise damaging this product.
- This product is not waterproof.
- Putting in items with sharp edges or tips may cause tears or holes in the fabric.
- This product may fade or stain other objects by wear or when wet or dampened with leaked water, rainwater, or perspiration.
- Leaving this product outdoors can result in fading and/or deterioration. Store this product away from direct sunlight after use.
- Store this product in a well-ventilated area away from heat and moisture.
- Do not drag this product when carrying it by its handles. It may cause the handle to tear, cause tears or holes in the fabric, or otherwise damage the handle and/or fabric.
- The inner side of the fabric is PVC-coated. Moisture may linger inside the product, so avoid long-term storage of items that do not tolerate moisture.
- When carrying, always hold the bag by the two handles bundled together. The sewn parts of the handles may tear when the handles are pulled outward.

### Maintenance

- Before using a product that has been in storage for a long time, check each part for abnormalities. If there are abnormalities, take the product to the retailer or contact Snow Peak Customer Service for inspection or repair.
- This product cannot be washed with water. To clean the product, wipe it using a tightly wrung cloth.
- If the product is dirty, gently wipe it using a soft cloth dampened with water or diluted mild detergent. Do not use store-bought cleaning wipes (that contain alcohol or other chemical) as they can discolor or deteriorate this product. Do not use solvents such as paint thinner and benzene.
- After removing the dirt, allow the product to dry completely in a well-ventilated place in the shade.

### Warranty

Snow Peak has taken all possible measures to ensure every product is durable and functions correctly. If you find any product defects, please contact the retailer where you purchased the product or Snow Peak Customer Service. If there are apparent defects in the product's manufacturing, the defective product will be repaired or exchanged free of charge. In other cases, Snow Peak will repair the product for an appropriate fee. The decision to repair or replace the product will be at our discretion. Snow Peak will not repair the product for any damage that occurred due to the following: 1. Material deterioration caused by age / 2. Damage caused by modifications or rough handling / 3. Damage caused by inappropriate use not mentioned in the instruction manual / 4. Damage caused by unexpected accidents / 5. Any damage other than defects in the manufacturing process / 6. Damage caused by dust or rust / 7. Damage and defects caused by dismantling the product / 8. Damage and defects caused by dropping, jolting or other shocks / 9. Deterioration or failure of parts due to friction / 10. Damage caused by the use of the product in combination with another manufacturer's products

### Repair

- If professional repairs are required, please contact the retailer where you purchased the product or Snow Peak Customer Service.
- When you request repairs, please make sure that the product is dry and clean.
- Please attach a memo or a tag indicating the necessary repair and please write details of how and when the damage occurred.
- Transportation and repair costs are determined as follows:
  1. Within warranty: The transportation cost (both ways) and repair cost will be covered by Snow Peak.
  2. Outside warranty: The transportation cost (both ways) and repair cost will be covered by the customer.