

Specification / スペック

- Set contents: Main body, Partition board
- Material: Polyester, Nylon, Polyethylene, Polypropylene, Polyacetal
- Size: 340×130×155(h)mm / 13.4"×5.1"×6.1"
- Weight: 700g / 24.7 oz
- セット内容: 本体、仕切り板
- 材質: ポリエステル、ナイロン、ポリエチレン、ポリプロピレン、ポリアセタール
- サイズ: 340×130×155 (h)mm
- 重量: 700g

Multi Container S

マルチコンテナ S

不明な点やお気付きの点がございましたら、販売店様または弊社ユーザーサービスまでお問い合わせください。

スノーピーク ☎0120-010-660 (9:00~17:00)
ユーザーサービス Email: userservice@snowpeak.co.jp

株式会社スノーピーク 〒955-0147 新潟県三条市中野原456
Tel.0256-46-5858 / Fax.0256-46-5860
www.snowpeak.co.jp

Snow Peak USA, Inc.
404 NW 23rd Avenue, Portland,
Oregon 97210, USA
Tel. +1 (888) 424-4916
Instagram. @snowpeakusa
Email. info@snowpeak.com
www.snowpeak.com



MADE IN CHINA

Multi Container マルチコンテナ

A sturdy container designed for easy organization, ideal for storing and carrying small gear.

小物ギアの保管・携帯に適した収納コンテナ。
汚れにくい底面とメッシュポケット付き。



UG-473

Instruction Manual / 取扱説明書 : Ver 1.00

Safety Precautions

Before use, please read thoroughly to ensure safety and avoid accidents.

CAUTION Misuse could result in injury to the user and/or damage to property.

●Before using the product, check each part for abnormalities. If there are abnormalities, take the product to the dealer or Snow Peak Customer Service for inspection or repair. ●This item is a cloth product. Do not leave this product near any heat source or put anything hot inside it. It may result in melting the fabric or otherwise damaging this product. ●This product is not waterproof. ●This product is made of fabric. When placing objects with sharp corners or tips, please take care not to damage the fabric inside. Doing so may cause tears or holes. ●This product may fade or stain other objects by wear or when wet or dampened with leaked water, rainwater, or perspiration. ●Leaving this product outdoors can result in fading and/or deterioration. Store this product away from direct sunlight after use. ●Store this product in a well-ventilated area away from heat and moisture. ●Do not drag the bag with contents inside. It may cause the handle to tear, cause tears or holes in the fabric, or otherwise damage the handle and/or fabric. ●When carrying, always hold the bag by the two handles bundled together. The sewn parts of the handles may tear when the handles are pulled outward. ●Do not put this product in a washing machine or dryer, as the fabric may lose its color or shrink. ●Always close the buckle when carrying the product. Do not pack it so full that the lid cannot be closed. Doing so may cause the items inside to fall out.

Maintenance

●Before using a product that has been in storage for a long time, check each part for abnormalities. If there are abnormalities, take the product to the retailer or contact Snow Peak Customer Service for inspection or repair. ●This product cannot be washed with water. To clean the product, wipe it using a tightly wrung cloth. ●If the product is dirty, gently wipe it using a soft cloth dampened with water or diluted mild detergent. Do not use store-bought cleaning wipes (that contain alcohol or other chemical) as they can discolor or deteriorate this product. Do not use solvents such as paint thinner and benzene. ●After removing the dirt, allow the product to dry completely in a well-ventilated place in the shade.

安全上の注意事項

ご使用前によく読んで予測される事故を回避し安全にご使用ください。

注意 ケガや本体破損、物品破損として拡大損害の原因となる行為を示します。

- ご使用前に本製品を点検し、各部に異常がないことを確認してください。異常が発見された場合は、直ちに使用を中止しお買い求めいただいた販売店様、または弊社ユーザーサービスに点検または修理を依頼してください。●本製品の素材は難燃性素材ではありません。火気周辺での放置や、熱いものを入れる行為はお止めください。生地が溶けるなど、破損の原因となるおそれがあります。●本製品は防水仕様ではありません。●本製品は布製品です。角や先端の鋭いものなどを入れる際の生地を傷つけないよう注意してください。破れや穴空きの原因になります。●摩擦、水濡れ、雨水、汗の影響によって色落ちや他のものへ色移りすることがあります。●屋外での放置は製品の劣化、退色の原因となります。ご使用後も、直射日光を避けて保管してください。●保管の際は高温多湿な場所を避け、通気性の良い場所に置いてください。●中身を入れた状態の製品を引きずらないでください。持ち手や生地の破損・破れ、穴空きの原因となります。●持ち運ぶ際には必ず2本のハンドルを束ねて持ってください。ハンドル本体の縫製部は外側に引っ張ると破損するおそれがあります。●洗濯機、乾燥機のご使用はおやめください。生地の色落ち、縮みの原因になります。●運搬時は必ずバックルを閉めてください。また蓋が閉められないほどの量を入れしないでください。中に入れたものが落下するおそれがあります。

メンテナンス

●長期間ご使用しなかった製品を再度お使いになる際は、本製品を点検し各部に異常がないことを確認してください。異常が発見された場合は、直ちに使用を中止しお買い求めいただいた販売店様、または弊社ユーザーサービスに点検または修理を依頼してください。●本製品は水洗いできません。汚れを落とす際にはよく絞った布などで拭き取ってください。●汚れが気になる場合は、水または薄めた中性洗剤を含ませた柔らかな布で軽く拭き取ってください。市販のお掃除シート(アルコール・薬剤を含むもの)は変色や劣化の原因となる場合がありますので使用しないでください。また、シンナーやベンジンなどの溶剤も使用しないでください。●汚れを取ったあとは、風通しの良い日陰で十分に乾燥させてください。