


BD-066 オフトン ウォームアダプター

この度は、スノーピーク製品をお買い上げいただき、誠にありがとうございます。本製品はキャンプ用寝袋(寝具)のライナーです。安全にご使用いただくためにも下記の取扱説明書をよく読んでからご使用ください。また、読み終わった後も大切に保管してください。説明内容で理解出来ない点及び製品に不具合が確認された際には直ちに使用を中止し、ご購入いただきました販売店様もしくは弊社ユーザーサービスまでお問い合わせください。

セット内容



スペック

- 材質: ポリエステル
- サイズ: 75×180cm
- 収納サイズ: φ16×25cm
- 重量: 800g

安全上の注意事項 ご使用の前によく読んで予測される事故を回避し安全にご使用ください。

⚠ 危険 明らかに生命に関わる重大な事故が予測される行為を示します。

- 火気厳禁: 本製品は難燃性ではありません。燃焼式のランタン、こんろ、ヒーターなど、熱源の近くで使用、放置はしないでください。また寝たばこはしないでください。
- 本製品を本来の使用用途以外で使用しないでください。思わぬ事故やケガの原因となります。

⚠ 警告 取扱いを誤った場合、使用者が死亡または重傷を負う可能性があることを示します。

- ご使用前に本製品を点検し、各部に異常がないことを確認してください。異常が発見された場合は、直ちに使用を中止しお買い求めいただいた販売店様、または弊社ユーザーサービスに点検または修理を依頼してください。


⚠ 注意 ケガや本体破損、物品破損として拡大損害の原因となる行為を示します。

- 本製品は、キャンプ用寝袋(寝具)の中にライナーとしてご使用いただく製品です。本製品単体では十分な保温性がないので、屋外や寒冷な場所での単独使用は避けてください。
- 無理な力で引っ張ったり、鋭利なものに接触させたりしないでください。破損の原因となります。
- 水や多くの湿気を受けた状態での保管及び汚れが付着したままの保管は、カビの発生原因となります。汚れを落とし、十分に乾燥させてから保管してください。
- 水濡れ、汗などによりほかのものへ色移りすることがあります。取扱いには十分ご注意ください。
- 乾燥した季節や環境では、静電気が起こる場合があります。特に化繊のシュラフや服との組み合わせにご注意ください。

使用方法


【使用方法】

- 本製品はシステムオフトン(スリム/ワイド)マットセット(BD-061/DB-071)、ダウンシステムオフトン(スリム/ワイド)マットセット(BD-060/DB-070)の掛け布団内側に装着して使用することが可能です。
- システムオフトンの内側にあるループに本製品のスナップボタン付テープを通し、スナップボタンを留めて取り付けます。(4箇所)



【収納方法】

- ① 本製品のファスナーを全て閉じて、平らにします。
- ② 収納ケースに入る幅に折って、巻いていきます。
- ③ 口紐を絞り込んでください。



【取扱い上の注意事項】

本製品は肌触りのよいフリース素材を使用しておりますが、素材の特性上、ご使用や洗濯を繰り返すことで毛玉(ピリング)が発生しやすくなっております。これは素材の性質によるものであり、品質上の問題ではありません。毛玉が気になる場合は、無理に引っ張らず、市販の毛玉取り器などをご使用ください。

メンテナンス

- 長期間使用しなかった製品を再度お使いになる際は、本製品を点検し各部に異常がないことを確認してください。異常が発見された場合は、直ちに使用を中止しお買い求めいただいた販売店様、または弊社ユーザーサービスに点検または修理を依頼してください。
- 濡れたまま、または湿気を帯びたまま保管するとカビや異臭、生地の色うつり、生地の劣化などのトラブルの原因となります。使用後は日陰で十分乾燥してから高温多湿を避け、直射日光の当たらない風通しのよい場所に保管してください。
- 次回のカンパに備え十分に保守、点検をしてください。

【洗濯上の注意事項】

本製品の洗濯をする際は、下記のことにご注意し、本体に取り付けられた注意表示をよくお読みください。

- 洗剤は洗濯洗剤をご使用ください。酸・アルカリ性などの洗剤は絶対に使用しないでください。
- 洗濯する際は洗濯ネットを必ず使用してください。
- 色落ちしますので、他の洗濯ものと一緒に洗わないでください。
- 洗濯により縮む場合があります。

品質保証について

お買い求めいただきました製品は万全を期していますが、万一不備な点がございましたら、お買い求めいただいた販売店様もしくは弊社または各製品に記載された連絡先にご相談ください。製造上の欠陥が原因の場合は無償で修理または交換させていただきます。その他の場合は適切な価格で修理させていただきます。修理、交換の判断は弊社の裁量によるものとさせていただきます。また、以下の場合は修理できない場合もありますので予めご了承ください。1. 素材の経年劣化による損害など商品の寿命 / 2. 改造および粗雑な取扱いによる故障 / 3. 取扱説明書で禁止されている取扱いによる故障 / 4. 不測の事故による商品の故障 / 5. その他製造上の欠陥以外による製品の故障 / 6. ゴミやさびによる故障 / 7. 分解したことによる不具合の発生または破損 / 8. 落下やその他の衝撃による部品の変形や破損による不具合 / 9. 摩擦によるパーツの変化及びそれによる故障 / 10. 他社製品との組み合わせによる故障

修理について

- 本格的な修理が必要な場合は、お買い求めになった販売店様または弊社ユーザーサービスまでお問い合わせください。
- 修理を依頼される場合は、必ず十分に乾燥させ、汚れをきれいに落としてください。
- 修理品には修理箇所がはっきりと解るように、必ずメモまたは荷札を付けてください。また破損時の状況をできるだけ詳しく書いたメモを添えてください。
- 修理品の運賃並びに修理費については以下のように規定させていただきます。1. 保証対象の場合: 往復運賃並びに修理費は弊社にて負担いたします。 / 2. 保証対象以外の場合: 往復運賃並びに修理費は、お客様のご負担とさせていただきます。


不明な点やお気付きの点がございましたら、**スノーピークユーザーサービス**
販売店様または弊社ユーザーサービスまで **☎ 0120-010-660** (9:00~17:00)
お問い合わせください。 Email: userservice@snowpeak.co.jp

株式会社スノーピーク 〒955-0147 新潟県三条市中野原456
Tel.0256-46-5858 Fax.0256-46-5860 www.snowpeak.co.jp MADE IN CHINA

BD-066 Ofuton Warm Adapter

Thank you for purchasing a Snow Peak product. This product is a liner for camping sleeping bags (bedding). For safety, read the following instruction manual before use. Please keep it safe for future reference. Finally, if you find anything that you do not understand in the description or any problems with the product, please stop use immediately and contact the retailer or Snow Peak Customer Service.

Contents



Specifications

- Material: Polyester
- Size: 75×180cm / 29.5"×70.9"
- Storage Size: φ16×25cm / dia.6.3"×9.8"
- Weight: 800g / 28.2oz

Safety Precautions: Before use, please read thoroughly to ensure safety and avoid accidents.

⚠ DANGER / Misuse could easily result in a serious accident or death.

- Keep fire away: This product is not fire-retardant. Do not use or leave this product near a combustion-based lantern, stove, heater, or other heat source. Do not smoke while in this product.
- Do not use this product for any purpose other than its intended use. Doing so may result in unexpected accidents or injuries.

⚠ WARNING / Misuse could result in serious injury or death.

- Before using the product, check each part for abnormalities. If there are abnormalities, take the product to the dealer or Snow Peak Customer Service for inspection or repair.


⚠ CAUTION / Misuse could result in injury to the user and/or damage to property.

- This product is designed to be used as a liner inside a camping sleeping bag (bedding). This product alone does not provide sufficient insulation. Avoid using it by itself outdoors or in cold environments.
- Do not pull with excessive force or expose the product to sharp objects. Doing so may cause damage.
- Storing the product while wet, exposed to high humidity, and with dirt still on it may cause mold to develop. Clean and dry thoroughly before storing.
- Color may transfer to other items due to exposure to water, sweat, or moisture. Please handle with appropriate care.
- Static electricity may occur in dry seasons or environments. Please take extra care when using this product with synthetic sleeping bags or clothing.

Instructions for Use


[Instructions for Use]

- This product can be attached to the inside of the comforter cover of the System Ofuton and Slim Mat / Wide Mat (BD-061/DB-071) and the Down System Ofuton and Slim Mat / Wide Mat (BD-060/DB-070).
- Insert the snap-button tape of this product through the loop located inside the System Ofuton, and fasten the snap button to secure it. (4 locations)



[How to store]

- ①Close all the zippers on this product and lay it flat.
- ②Fold it to a width that fits into the storage case, then roll it up.
- ③Tighten the drawstring.



[Handling precautions]

This product is made from soft fleece material. However, due to the nature of the fabric, repeated use and washing may cause pilling. This is a natural characteristic of the material and not a quality defect. If pilling is a concern, do not pull it off forcefully. Instead, use a commercially available fabric shaver or pilling remover.

Maintenance

- Before using a product that has been in storage for a long time, check each part for abnormalities. If there are abnormalities, take the product to the retailer or contact Snow Peak Customer Service for inspection or repair.
- Storing the product while wet or damp may cause mold, unpleasant odors, color transfer, or fabric deterioration. After use, dry it thoroughly in the shade, and store it in a well-ventilated area away from high temperatures, high humidity, and direct sunlight.
- Thoroughly maintain and inspect your equipment in preparation for your next camping trip.

[Washing precautions]

When washing this product, please follow the instructions below and carefully read the caution label attached to the product.

- Use laundry detergent. Never use acidic or alkaline detergents.
- Always use a laundry net when washing this product.
- Do not wash with other laundry items, as the color may fade.
- It may shrink after washing.

Warranty

Snow Peak has taken all possible measures to ensure every product is durable and functions correctly. If you find any product defects, please contact the retailer where you purchased the product or Snow Peak Customer Service. If there are apparent defects in the product's manufacturing, the defective product will be repaired or exchanged free of charge. In other cases, Snow Peak will repair the product for an appropriate fee. The decision to repair or replace the product will be at our discretion. Snow Peak will not repair the product for any damage that occurred due to the following:

1. Material deterioration caused by age / 2. Damage caused by modifications or rough handling / 3. Damage caused by inappropriate use not mentioned in the instruction manual / 4. Damage caused by unexpected accidents / 5. Any damage other than defects in the manufacturing process / 6. Damage caused by dust or rust / 7. Damage and defects caused by dismantling the product / 8. Damage and defects caused by dropping, jolting or other shocks / 9. Deterioration or failure of parts due to friction / 10. Damage caused by the use of the product in combination with another manufacturer's products

Repair

- If professional repairs are required, please contact the retailer where you purchased the product or Snow Peak Customer Service.
- When you request repairs, please make sure that the product is dry and clean.
- Please attach a memo or a tag indicating the necessary repair and please write details of how and when the damage occurred.
- Transportation and repair costs are determined as follows. 1. Within warranty: The transportation cost (both ways) and repair cost will be covered by Snow Peak. / 2. Outside warranty: The transportation cost (both ways) and repair cost will be covered by the customer.

Snow Peak USA, Inc. 404 NW 23rd Avenue, Portland, Oregon 97210, USA
Tel. +1 (888) 424-4916 / Instagram. @snowpeakusa
Email. info@snowpeak.com / www.snowpeak.com

Snow Peak, Inc. 456, Nakanohara, Sanjo-Shi, Niigata 955-0147 Japan
Tel. +81 256-46-5858 / Fax. +81 256-46-5860
www.snowpeak.co.jp

MADE IN CHINA