snow peak
outdoor lifestyle creator since1958

取扱説明書：Ver 1.00

CK-036
IGTライトトレー ハーフユニット

この度は、スノーピーク製品をお買い上げいただき、誠にありがとうございます。本製品は、アイアングリルテーブル（以下、IGT）の天板です。安全にご使用いただくためにも下記の取扱説明書をよく読んでからご使用ください。また、読み終わった後も大切に保管してください。説明内容で理解出来ない点及び製品に不具合が確認された際には直ちに使用を中止し、ご購入いただきました販売店様もしくは弊社ユーザーサービスまでお問い合わせください。

スペック

●セット内容:天板本体×2
●材質:素地／アルミニウム合金、表面仕上／カチオン電着塗装
●サイズ:125×360×10（h）mm
●重量:190g（1枚あたり）
●耐荷重:10kg（1枚あたり）

安全上の注意事項　ご使用の前によく読んで予測される事故を回避し安全にご使用ください。

⚠警告　取扱いを誤った場合、使用者が死亡または重傷を負う可能性があることを示します。

●ご使用の前に本製品を点検し、各部に異常がないことを確認してください。異常が発見された場合は、直ちに使用を中止しお買い求めいただいた販売店様、または弊社ユーザーサービスに点検または修理を依頼してください。●本製品とあわせて使用する製品の取扱説明書を必ずお読みください。●本天板の上で燃焼器を使わないでください。製品特性上非常に軽量なため天板間の隙間に燃焼器の脚や支えの部分が入った場合に隙間が広がり燃焼器がバランスを崩し転倒するおそれがあります。●IGTと組み合わせて使用する燃焼器の熱により、本製品も高温になります。ヤケドのおそれがありますので、十分注意してください。●燃焼器の隣に設置して使用する際は、ガスカートリッジや可燃物、その他熱の影響を受けやすいものを0.5ユニット（125mm）以内に置かないでください。爆発、変形、火災のおそれがあります。●直射日光の当たる場所では、本製品が高温になる場合があります。ヤケドのおそれがありますので注意してください。●本製品に座ったり乗ったりしないでください。製品の破損や転倒によるケガなど、思わぬ事故につながるおそれがあります。

⚠注意　ケガや本体破損、物品破損として拡大損害の原因となる行為を示します。

●本製品は用途以外に使用しないでください。思わぬケガや事故のおそれがあります。●本製品はロゴが上にくるように取り付けてお使いください。誤った向きで使用すると、本来の性能を発揮できないおそれがあります。●本製品をIGTに設置する際は、確実にフレームへ取り付けられていることを確認してから手を放してください。落下のおそれがあります。●積み重ねやフレームへの着脱の際は、指や手を挟まないよう注意してください。●本製品には金属製の板を使用しております。端部処理を施しておりますが、端部で指を切るおそれがあります。取扱いには十分注意してください。●本製品には爪状の突起があります。衣服や細い線材などが引っ掛からないよう、取扱いには十分注意してください。●本製品の上で直接調理や作業をしないでください。表面の傷や変形、表面処理の劣化の原因となります。●本製品は端部形状の特性上、テーブル上に設置した器具の脚部などが製品どうしの隙間に入り込み、横方向へ力が加わると、隣接する製品の上に乗り上がることがあります。製品どうしの隙間や段差に指やものを入れないでください。●本製品の上に設置する製品は、本製品の平面側にだけ接するように置いてください。傾斜のついた側面側に接すると本製品が動き、乗り上がるおそれがあり、大変危険です。●本製品に強い衝撃や荷重を与えないでください。変形や破損の原因となります。●金属製のヘラや硬いたわしなどは使用しないでください。傷や変形、表面処理の劣化の原因となります。●傷により金属の素地が露出すると、白サビが発生し、外観を損なうおそれがあります。運搬や取扱いには十分注意してください。●熱源の近くで使用したり、熱したダッチオーブンや鍋などを置いたりしないでください。変色や変形、表面処理の劣化の原因となります。●本製品は常設用ではありません。重量物を載せたまま長期間放置しないでください。変形のおそれがあります。●湿度の高い場所や温度変化の激しい場所で保管しないでください。結露によるサビの原因となります。●本製品を積み重ねて保管する際は、安定した平らな場所で保管してください。製品の転倒や落下のおそれがあります。

メンテナンス方法

●長期間ご使用しなかった製品を再度お使いになる際は、本製品を点検し、各部に異常がないことを確認してください。異常が発見された場合は、直ちに使用を中止しお買い求めいただいた販売店様、または弊社ユーザーサービスに点検または修理を依頼してください。●軽い汚れや水分が付着した場合は、速やかに乾いた布で拭き取ってください。酸性またはアルカリ性の洗剤や溶剤は使用しないでください。表面処理の劣化を早めます。●塩分（調味料等）やその他の薬品が付着した場合は、固く絞った布でよく拭き取り、十分に乾燥させてください。●メンテナンスをおこなう際は、手袋などの保護具をご使用ください。●保管する場合は、直射日光の当たらない、風通しが良く湿気の少ない場所に保管してください。

品質保証について

お買い求めいただきました製品は万全を期していますが、万一不備な点がございましたら、お買い求めいただいた販売店様もしくは弊社または各製品に記載された連絡先にご相談ください。製造上の欠陥が原因の場合は無償で修理または交換させていただきます。その他の場合は適切な価格で修理させていただきます。修理、交換の判断は弊社の裁量によるものとさせていただきます。また、以下の場合は修理できない場合もありますので予めご了承ください。 1. 素材の経年劣化による損害など製品の寿命 / 2. 改造及び粗雑な扱いによる故障 / 3. 取扱説明書で禁止されている取扱いによる故障 / 4. 不測の事故による製品の故障 / 5. その他製造上の欠陥以外による製品の故障 / 6. ゴミやさびによる故障 / 7. 分解したことによる不具合の発生または破損 / 8. 落下やその他の衝撃による部品の変形や破損による不具合 / 9. 摩擦によるパーツの変化およびそれによる故障 / 10. 他社製品との組み合わせによる故障

不明な点やお気付きの点がございましたら、販売店様または弊社ユーザーサービスまでお問い合わせください。
スノーピークユーザーサービス
0120-010-660（9:00～17:00）
Email:userservice@snowpeak.co.jp

株式会社スノーピーク　〒955-0147 新潟県三条市中野原456
Tel. 0256-46-5858 / Fax. 0256-46-5860
www.snowpeak.co.jp

MADE IN CHINA

snow peak
outdoor lifestyle creator since1958

Instruction Manual : Ver 1.00

CK-036
IGT Light Tray Half Unit

Thank you for purchasing a Snow Peak product. This product is a top panel for the Iron Grill Table ("IGT"). For safety, read the following instruction manual before use. Please keep it safe for future reference. Finally, if you find anything that you do not understand in the description or any problems with the product, please stop use immediately and contact the retailer or Snow Peak Customer Service.

Specifications

- Set Contents: Top Panel Body (×2)
- Base Material / Aluminum Alloy, Surface Finish / Cationic Electrodeposition Coating
- Size：125×360×10 (h) mm / 4.9”×14.2”×0.4”(h)
- Weight：190g / 6.7oz (per panel)
- Max. load: 10kg / 22lbs (per panel)

Safety Precautions: Before use, please read thoroughly to ensure safety and avoid accidents.

⚠ WARNING / Misuse could result in serious injury or death.

• Before using the product, check each part for abnormalities. If there are abnormalities, take the product to the dealer or Snow Peak Customer Service for inspection or repair. • Be sure to read the instruction manual for any product used in conjunction with this product. • Do not use combustion appliances on this tabletop. Due to its lightweight design, an appliance leg or support caught between the panels may widen the gap, causing the appliance to become unstable and tip over. • When this product is used next to a burner installed in the IGT, heat from the burner may cause this product to become hot. Use caution to avoid burns. • When using this product next to a burner, do not place gas canisters, flammable materials, or other heat-sensitive objects within 0.5 unit (4.9 in.) of the burner. Doing so may result in explosion, deformation, or fire. • The product may become hot when exposed to direct sunlight. Use caution to avoid burns. • Do not sit or stand on this product. Doing so may damage the product or cause it to tip over, resulting in injury.

⚠ CAUTION / Misuse could result in injury to the user and/or damage to property.

• Do not use this product for any purpose other than its intended use. Failure to do so may result in injury or accidents. • To use the tray, install it so that the logo faces upward. If it is placed incorrectly, the product may not be able to deliver its full performance. • When installing this product on the IGT, make sure it is securely attached to the frame before releasing it. Otherwise, it may fall. • Be careful not to pinch your fingers or hands when stacking this product or installing or removing it from the frame. • This product is made of sheet metal. Although the edges have been finished, they may still cause cuts. Handle with care. • This product has claw-shaped projections. Handle with care to prevent clothing, thin cords, or similar items from getting caught on them. • Do not cook directly on this product or use it as a work surface. Doing so may cause scratches, deformation, or deterioration of the surface finish. • Due to the shape of the edges of this product, the legs of cookware or other equipment placed on the table may become caught in the gap between adjacent products. If lateral force is applied, this product may ride up onto the adjacent product. Do not insert your fingers or any objects into the gaps or level differences between adjacent products. • Place any item on this product so that it comes into contact only with the flat side. If the item comes into contact with the sloped side, this product may move and ride up, creating a serious hazard. • Do not subject this product to strong impacts or excessive loads. Doing so may cause deformation or damage. • Do not use metal spatulas, hard scouring pads, or similar tools. Doing so may cause scratches, deformation, or peeling of the coating. • Scratches may expose the bare metal surface, which may result in corrosion and affect the appearance of the product. Handle and transport this product with care. • Do not use this product near heat sources or place hot Dutch ovens, pots, or similar cookware on it. Heat may cause discoloration, deformation, or deterioration of the surface finish. • This product is not intended for permanent installation. Do not leave heavy objects on it for extended periods, as this may cause deformation. • Do not store this product in humid locations or where it is exposed to rapid temperature changes. Condensation may cause corrosion. • When stacking this product for storage, store it on a stable, level surface. Otherwise, the product may tip over or fall.

Maintenance

• Before using a product that has been in storage for a long time, check each part for abnormalities. If there are abnormalities, take the product to the retailer or contact Snow Peak Customer Service for inspection or repair. • Wipe off light dirt or moisture immediately using a dry cloth. Do not use acidic or alkaline detergents or solvents. Doing so may accelerate deterioration of the surface finish. • If salt (such as seasonings) or other chemicals adhere to the product, wipe them off thoroughly with a well-wrung cloth and dry the product completely. • Wear gloves and other protective equipment when performing maintenance. • Store this product in a well-ventilated, low-humidity location away from direct sunlight.

Warranty

Snow Peak has taken all possible measures to ensure every product is durable and functions correctly. If you find any product defects, please contact the retailer where you purchased the product or Snow Peak Customer Service. If there are apparent defects in the product's manufacturing, the defective product will be repaired or exchanged free of charge. In other cases, Snow Peak will repair the product for an appropriate fee. The decision to repair or replace the product will be at our discretion. Snow Peak will not repair the product for any damage that occurred due to the following: 1. Material deterioration caused by age / 2. Damage caused by modifications or rough handling / 3. Damage caused by inappropriate use not mentioned in the instruction manual / 4. Damage caused by unexpected accidents / 5. Any damage other than defects in the manufacturing process / 6. Damage caused by dust or rust / 7. Damage and defects caused by dismantling the product / 8. Damage and defects caused by dropping, jolting or other shocks / 9. Deterioration or failure of parts due to friction / 10. Damage caused by the use of the product in combination with another manufacturer's products

Snow Peak USA, Inc.
404 NW 23rd Avenue, Portland, Oregon 97210, USA
Tel. +1 (888) 424-4916 / Instagram. @snowpeakusa
Email. info@snowpeak.com / www.snowpeak.com

Snow Peak, Inc.
456, Nakanohara, Sanjo-Shi, Niigata 955-0147 Japan
Tel. +81 256-46-5858 / Fax. +81 256-46-5860
www.snowpeak.co.jp

MADE IN CHINA