


## CK-451-BK / CK-451-KR フラットバーナー専用ブラックコンバージョンキット

△ リッドトレーは、フラットバーナーに適切にフィットするよう設計されているため、IGT規格の1ユニットサイズよりもわずかに大きい寸法となっております。そのため、本製品はIGT規格製品ではありません。IGTフレーム内で本製品を複数使用する場合など、組み合わせによっては正しく装着できないことがあります。あらかじめご了承のうえ、ご使用ください。


この度は、スノーピーク製品をお買い上げいただき、誠にありがとうございます。本製品はフラットバーナー専用のリッド(蓋)とトッププレートのセットです。安全にご使用いただくためにも下記の取扱説明書をよく読んでからご使用ください。また、読み終わった後も大切に保管してください。説明内容で理解出来ない点及び製品に不具合が確認された際には直ちに使用を中止し、購入いただきました販売店様もしくは弊社ユーザーサービスまでお問い合わせください。

### セット内容(各部の名称)

リッドトレー



トッププレート



取扱説明書(本書)

### スペック

リッドトレー

●材質:ステンレス(耐熱塗装)

●サイズ:363×253×15(h)mm

●重量:760g

トッププレート

●材質:ステンレス(ふっ素樹脂加工)

●サイズ:360×250×21.5(h)mm

●重量:710g

### 安全上の注意事項 ご使用の前によく読んで予測される事故を回避し安全にご使用ください。

#### △ 危険 明らかに生命に関わる重大な事故が予測される行為を示します。

●本製品と併せてご使用になる各アイテムの取扱説明書を必ずお読みください。特に、フラットバーナー本体の取扱説明書をよく読み、安全に注意してご使用ください。

#### △ 警告 取扱いを誤った場合、使用者が死亡または重傷を負う可能性があることを示します。

●ご使用の前に、本製品を点検し各部に異常がないことを確認してください。異常が発見された場合は、直ちに使用を中止し、お買い求めいただいた販売店様、または弊社ユーザーサービスに点検または修理を依頼してください。

●直射日光の当たる場所や熱源の近くに置かないでください。本製品が不意に熱くなりヤケドを負う危険性があります。

●本製品には座ったり乗ったりしないでください。本製品の破損・転倒からのケガなど思わぬ事故につながるおそれがあり大変危険です。

#### 【リッドトレーについて】

●IGTと組み合わせてご使用の際は、他の燃焼器からの熱により本製品にも熱が伝わり熱くなります。ヤケドなどの事故に十分ご注意ください。

●燃焼器と隣接して本製品を使用する際はガスカートリッジや可燃性のもの、または熱の影響を受けやすいものを0.5ユニット(125mm)以内に置かないでください。爆発、変形、火災のおそれがあります。

●フラットバーナーのリッドとして使用する際には、必ずフラットバーナーが完全に冷めてから被せてください。ヤケドや本製品の変色、変形などのおそれがあります。

#### 【トッププレートについて】

●使用時および使用直後は、本体やトッププレートに触れないでください。高温になっており、ヤケドのおそれがあります。

●トッププレートの付け替えや収納は、本体が完全に冷めてからおこなってください。

#### △ 注意 ケガや本体破損、物品破損として拡大損害の原因となる行為を示します。

●本製品は鋼板を使用しております。端部処理を施しておりますが、端部で指を切るなどの危険性がありますので、取扱いには十分注意してください。

●本製品は常設用ではありません。本製品に重量物を載せたままにすると変形につながるおそれがあります。

●金属製のヘラや硬い素材のたわし、磨き粉などを用いて汚れを落とさないでください。傷や変形、塗装のはがれにつながるおそれがあります。汚れを落とす際は「メンテナンスについて」をご参照ください。

●本製品の上で直接調理や作業を行わないでください。本製品の傷や変形、塗装のはがれにつながるおそれがあります。

●本製品に強い衝撃を与えないでください。本製品の変形・破損の原因となります。

●結露によりサビにつながるおそれがありますので、湿度が高い場所や温度変化の激しい場所での保管はしないでください。

●本製品は傷がつくことにより、金属の素地が露出します。運搬や収納時、取扱いにご注意ください。

●本製品を使用用途以外で使用しないでください。思わぬケガや事故のおそれがあります。

#### 【リッドトレーについて】


●本製品をIGTまたはTAKIBI MYテーブルに設置する際は確実にフレームに設置したことを確認してから手を放してください。確実に設置されていないと、本製品が落下するおそれがあります。

●本製品をバーベキューボックスなどの熱源の近くで使用すると、熱により変色や歪みが発生します。

●熱したダッチオーブンや鍋などを本製品の上に置くと、熱により本製品の塗膜が変色・融解する可能性があります。

### 【フラットバーナーへの取り付け例】

リッドトレーをフラットバーナーの真上から降ろして蓋してください。



トッププレートの取り付け方はフラットバーナー本体の説明書をご確認ください。



### 【TAKIBI MYテーブルへの取り付け】

TAKIBI MYテーブルが完全に開いていることを確認し、本製品の"切欠き"にTAKIBI MYテーブルのピンが挟まるように取り付けてください。

※4箇所すべてが正しく取り付けられていることを必ずご確認ください。

※本製品は塗装品です。TAKIBI MYテーブルへの取り付け部は塗装がはがれますのであらかじめご了承ください。

△ 注意:TAKIBI MYテーブルに取り付けて使用する際は"切欠き"より外側に重量物または、液体が入った容器を置かないでください。



### メンテナンスについて

●長期間ご使用しなかった製品を再度お使いになる際は、本製品を点検し各部に異常がないことを確認してください。異常が発見された場合は、直ちに使用を中止し、お買い求めいただいた販売店様、または弊社ユーザーサービスに点検または修理を依頼してください。

●メンテナンスされる際は手袋などの保護具をご使用ください。

●保管をする場合は、直射日光の当たらない、風通しの良い湿気の少ない場所に保管してください。

#### 【リッドトレーについて】

●軽い汚れや水分が付着した場合は、速やかに乾いた布で拭き取ってください。

●塩分(調味料等)やその他の薬品が付着した場合は、固く絞った布でよく拭き取り、十分に乾燥させてください。

#### 【トッププレートについて】

●柔らかいスポンジたわしに中性洗剤をつけて洗ってください。

●洗浄後、乾いた布で水気を拭き取り、風通しの良い日陰で乾燥させてください。

### 品質保証について

お買い求めいただきました製品は万全を期していますが、万一不備な点がございましたら、お買い求めいただいた販売店様もしくは弊社または各製品に記載された連絡先にご相談ください。製造上の欠陥が原因の場合は無償で修理または交換させていただきます。その他の場合は適切な価格で修理させていただきます。修理、交換の判断は弊社の裁量によるものとさせていただきます。また、以下の場合は修理できない場合もありますので予めご了承ください。

1.素材の経年劣化による損害など商品の寿命

2.改造および粗雑な取扱いによる故障

3.取扱説明書で禁止されている取扱いによる故障

4.不測の事故による商品の故障

5.その他製造上の欠陥以外による製品の故障

6.ゴミやさびによる故障

7.分解したことによる不具合の発生または破損

8.落下やその他の衝撃による部品の変形や破損による不具合

9.摩擦によるバーツの変化及びそれによる故障

10.他社製品との組み合わせによる故障

### 修理について

●本格的な修理が必要な場合は、お買い求めになった販売店様または弊社ユーザーサービスまでお問い合わせください。●修理を依頼される場合は、必ず十分に乾燥させ、汚れをきれいに落としてください。●修理品には修理箇所がはっきりと解るように、必ずメモまたは荷札を付けてください。また破損時の状況をできるだけ詳しく書いたメモを添えてください。●修理品の運賃並びに修理費については以下のように規定させていただきます。

1.保証対象の場合:往復運賃並びに修理費は弊社にて負担いたします。/ 2.保証対象以外の場合:往復運賃並びに修理費は、お客様のご負担とさせていただきます。


## CK-451-BK / CK-451-KR Black Conversion Kit for Flat Burner

**⚠** The lid tray is designed to fit the flat burner perfectly, so its dimensions are slightly larger than a single unit size of the IGT standard. Therefore, this product is not an IGT standard product. When using multiple units of this product in an IGT frame, please note that it may not fit perfectly depending on combination.


Thank you for purchasing a Snow Peak product. This product is a lid and top plate set manufactured exclusively for the flat burner. For safety, read the following instruction manual before use. Please keep it safe for future reference. Finally, if you find anything that you do not understand in the description or any problems with the product, please stop use immediately and contact the retailer or Snow Peak Customer Service.

### Contents (Name of the Parts)

Lid Tray



Top Plate



Instruction Manual  
(This Manual)

### Specifications

Lid Tray

- Material:Stainless Steel (Heat-Resistant Coating)
- Size:363x253x15(h)mm / 14.3"×10.0"×0.6"(h)
- Weight:760g / 26.8oz

Top Plate

- Material:Stainless Steel (Fluoropolymer Coating)
- Size:360x250x21.5(h)mm / 14.2"×9.8"×0.8"(h)
- Weight:710g / 25.0oz

### Safety Precautions: Before use, please read thoroughly to ensure safety and avoid accidents.

#### **⚠ DANGER / Misuse could easily result in a serious accident or death.**

- Please be sure to read the instruction manual for each item used in conjunction with this product. Please read the flat burner instruction manual carefully and use the product safely.

#### **⚠ WARNING / Misuse could result in serious injury or death.**

- Before using the product, check each part for abnormalities. If there are abnormalities, take the product to the dealer or Snow Peak Customer Service for inspection or repair.
- Do not expose the product to direct sunlight or place it near a heat source. The product will become hot, causing a potential for burns or injury.
- Do not sit or ride on this product. Doing so is extremely dangerous due to risk of an unexpected accident, damage to the product or injury from a fall.
- [About the Lid Tray]
- When used in combination with IGT, heat from other combustors will be transferred to this product, causing it to become hot. Please use caution to avoid accidents and burns.

- When using this product adjacent to a burner or grill, do not place gas canisters, flammable materials, or heat-sensitive objects within 0.5 unit (4.9") of the product. Using these items close to the product may result in explosion, deformation, or fire.
- When using this product as a lid for the Flat Burner, be sure to put it on the Flat Burner after it has completely cooled down. There is a risk of burns, and/or discoloration or deformation of this product.
- [About the Top Plate]
- Do not touch the main body or top plate during or immediately after use. They become very hot and may cause burns.
- Replace or store the top plate only after the burner has completely cooled down.

#### **⚠ CAUTION / Misuse could result in injury to the user and/or damage to property.**


- This product is made of a steel plate. Although the edges are treated, there is a risk of cutting fingers on the edges, so please handle with care.
- This product is not for permanent installation. Leaving heavy objects on this product may lead to deformation.
- Do not use metal spatulas, hard brushes, or abrasive cleaners to remove dirt. Doing so may cause scratches, deformation, or peeling of the paint. Refer to "Maintenance" when removing stains.
- Do not cook or work directly on the product. Doing so may result in scratches, deformation, or peeling of the paint on the product.
- Do not subject this product to drops or strong jolts, as they may cause deformation or damage.
- Do not store the product in a humid place or in a place where the temperature changes rapidly, as condensation may lead to rusting.

- Scratches on this product will expose the bare metal. Handle the product with care when moving and storing it.
- Do not use this product for anything other than its intended use, doing so may result in unexpected injury or accident.
- [About the Lid Tray]
- When installing this product on the IGT or Takibi MY Table, make sure that it is securely installed on the frame before releasing your hand. If the product is not installed properly it may fall.
- If this product is used near a heat source such as a barbecue box, discoloration or distortion will occur due to the heat.
- If a hot Dutch oven or pot is placed on the product, the heat may cause discoloration or melt the product's coating.

### Instructions for Use

#### [Example of covering the Flat Burner]

Cover the Flat Burner by placing the lid tray on the burner straight down.




For details on how to attach the top plate, refer to the Flat Burner Instruction Manual.


#### [Installation on Takibi MY Table]

Make sure Takibi MY Table is completely open, and install the table so that its pins are inserted into the "notch" of this product.

- \* Be sure to check that all four places are properly installed.
- \* Please note that this product is painted and the paint will peel off at the attachment points.



**⚠ CAUTION:** When using the Takibi MY Table, do not place heavy objects or containers of liquids outside of the "notch".



### Maintenance

- Before using a product that has been in storage for a long time, check each part for abnormalities. If there are abnormalities, take the product to the retailer or contact Snow Peak Customer Service for inspection or repair.
- Please use gloves and other protective equipment when performing maintenance.
- Store this product away from direct sunlight in a well-ventilated and dry location.
- [About the Lid Tray]
- If light dirt or moisture adheres to the surface, wipe it off with a dry cloth as soon as possible.

- If salt (seasonings, etc.) or other chemicals adhere to the product, wipe thoroughly with a tightly wrung cloth and dry thoroughly.
- [About the Top Plate]
- Wash it using a soft sponge and mild detergent.
- After washing, wipe off any moisture using a dry cloth and allow it to dry in a well-ventilated, shaded area.

### Warranty

Snow Peak has taken all possible measures to ensure every product is durable and functions correctly. If you find any product defects, please contact the retailer where you purchased the product or Snow Peak Customer Service. If there are apparent defects in the product's manufacturing, the defective product will be repaired or exchanged free of charge. In other cases, Snow Peak will repair the product for an appropriate fee. The decision to repair or replace the product will be at our discretion. Snow Peak will not repair the product for any damage that occurred due to the following.

1. Material deterioration caused by age
2. Damage caused by modifications or rough handling
3. Damage caused by inappropriate use not mentioned in the instruction manual
4. Damage caused by unexpected accidents
5. Any damage other than defects in the manufacturing process

6. Damage caused by dust or rust
7. Damage and defects caused by dismantling the product
8. Damage and defects caused by dropping, jolting or other shocks
9. Deterioration or failure of parts due to friction
10. Damage caused by the use of the product in combination with another manufacturer's products

### Repair

- If professional repairs are required, please contact the retailer where you purchased the product or Snow Peak Customer Service. • When you request repairs, please make sure that the product is dry and clean. • Please attach a memo or a tag indicating the necessary repair and please write details of how and when the damage occurred. • Transportation and repair costs are determined as follows.

1.Within warranty: The transportation cost (both ways) and repair cost will be covered by Snow Peak. / 2.Outside warranty: The transportation cost (both ways) and repair cost will be covered by the customer.

#### Snow Peak USA, Inc.

404 NW 23rd Avenue, Portland, Oregon 97210, USA  
Tel. +1 (888) 424-4916 / Instagram. @snowpeakusa  
Email. info@snowpeak.com / www.snowpeak.com

#### Snow Peak, Inc.

456, Nakanobara, Sanjo-Shi, Niigata 955-0147 Japan  
Tel. +81 256-46-5858 / Fax. +81 256-46-5860  
www.snowpeak.co.jp

MADE IN KOREA