

ET-26SU006

ステンレスクーリングパック 2個セット

この度は、スノーピーク製品をお買い上げいただき、誠にありがとうございます。本製品はステンレス製の保冷剤です。安全にご使用いただくためにも下記の取扱説明書をよく読んでからご使用ください。また、読み終わった後も大切に保管してください。説明内容で理解出来ない点及び製品に不具合が確認された際には直ちに使用を中止し、ご購入いただきました販売店様もしくは弊社ユーザーサービスまでお問い合わせください。

スペック

- セット内容:本体(×2)
- 材質:本体/ステンレス鋼、内容物/純水95%、エタノール5%
- サイズ:約116×176×13(h)mm
- 耐冷・耐熱温度:-35~90℃
- 重量:約450g

安全上の注意事項 ご使用の前によく読んで予測される事故を回避し安全にご使用ください。

⚠ 注意 ケガや本体破損、物品破損として拡大損害の原因となる行為を示します。

- ご使用前に本製品を点検し、各部に異常がないことを確認してください。異常が発見された場合は、直ちに使用を中止しお買い求めいただいた販売店様、または弊社ユーザーサービスに点検または修理を依頼してください。
- 本製品は保冷用です。製品本来の目的以外の用途には使用しないでください。
- 本製品を、熱冷ましや患部の冷却など、氷のうとして使用しないでください。凍傷のおそれがあります。
- 本製品を、凍冷ましに当てないでください。凍傷のおそれがあります。
- 火に近づけたり、加熱しないでください。破裂によるケガや破損のおそれがあります。
- 鋭利なものや突起物との接触に注意してください。傷や破損の原因になります。
- 破損や液漏れが生じた場合は、使用しないでください。万一、内容物が衣類に付着した場合は、濡れたタオルで拭き取ってください。内容物は口に入れないでください。万一、口に入った場合は、直ちに医師の診察を受けてください。
- 直射日光の下で使用・放置しないでください。機能低下や表面が熱くなり、ヤケドのおそれがあります。
- 小児の手の届かない場所に保管してください。
- 廃棄の際は、お住まいの自治体の分別区分に従って処分してください。
- 落下した製品は液漏れなどの異常がないかを確認してから使用してください。

使用方法

冷凍庫で完全に凍結させてからご使用ください。(目安時間:約4~8時間)
凍結が不十分な場合、十分な保冷効果が得られません。

[ご使用時の注意]

本製品の性能を正しく発揮させるために下記の点に注意してください。

- 冷凍庫内が-20℃に達しない場合、凍結しないことがあります。
- 冷凍庫の設定温度を最低温度にしても凍結しにくい場合は、冷凍庫内をできるだけ空に近い状態にし、冷気の吹き出し口付近に置いてください。
- 完全に氷結体になるまでの時間はあくまで目安です。冷凍庫の性能や使用条件により、それ以上かかる場合があります。
- 凍結させる前や使用後はきれいに洗ってから使用、保管してください。
- 冷凍庫に入れる前に、本体に付着した水分は拭き取ってください。凍結時間に影響が出る場合があります。
- 他の保冷剤や凍結していない食材と重ねたり、触れさせた状態で凍結させると、凍結しにくくなるほか、使用に支障が出るおそれがあります。重ねずに冷凍してください。
- 生の食材に直接触れないようにしてください。

品質保証について

●本製品は、使用頻度や保管環境により性能が低下します。十分な保冷効果が得られなくなった場合は、新しい製品への交換をおすすめします。
●お買い求めいただきました製品には万全を期していますが、万一不備な点がございましたら、お買い求めの販売店または弊社までご相談ください。製造上の欠陥が原因の場合は無償で修理または交換させていただきます。その他の場合は適正な価格にて修理させていただきますので予めご了承ください。また以下の場合には修理、交換が出来ない場合がありますのでご注意ください。

1. 素材の経年劣化による損害など製品の寿命
2. 改造及び粗雑な扱いによる故障
3. 取扱説明書で禁止されている取扱いによる故障
4. 不慮の事故による製品の故障
5. その他製造上の欠陥以外による製品の故障
6. ゴミやさびによる故障
7. 分解したことによる故障
8. 落下やその他衝撃による部品の変形や破損による不具合
9. 摩耗によるパーツの変化およびそれによる故障
10. 他社製品との組み合わせによる故障

ET-26SU006

Stainless Cooling Pack Set

Thank you for purchasing a Snow Peak product. This product is a stainless steel cooling pack. For safety, read the following instruction manual before use. Please keep it safe for future reference. Finally, if you find anything that you do not understand in the description or any problems with the product, please stop use immediately and contact the retailer or Snow Peak Customer Service.

Specifications

- Set Contents: Main Body (×2)
- Material: Body: Stainless Steel, Contents: Pure Water 95% / Ethyl Alcohol 5%
- Size: Approx. 116×176×13(h)mm / 4.6"×6.9"×0.5"
- Operating Temperature Range: -35 to 90°C / -31°F to 194°F
- Weight: Approx. 450g / 15.9 oz

Safety Precautions: Before use, please read thoroughly to ensure safety and avoid accidents.

⚠ CAUTION / Misuse could result in injury to the user and/or damage to property.

- Before using the product, check each part for abnormalities. If there are abnormalities, take the product to the dealer or Snow Peak Customer Service for inspection or repair.
- This product is designed to keep items cold. Do not use the product for any purpose other than its intended use.
- Do not use this product as an ice pack to reduce fever or cool injured areas. Doing so may cause frostbite.
- Do not apply this product directly to your skin. Doing so may cause frostbite.
- Do not place it near fire or heat. Doing so may cause injury or damage due to an explosion.
- Avoid contact with sharp or protruding objects. Doing so may cause scratches or damage.
- Do not use this product if it is damaged or leaking. If the leaked contents come into contact with clothing, wipe them off using a damp towel. Do not ingest the contents. If the contents are accidentally ingested, seek medical attention immediately.
- Do not use or leave this product in direct sunlight. Doing so may reduce its performance or cause the surface to become hot, which may result in burns.
- Keep out of reach of children.
- Dispose of the product according to the waste disposal regulations of your local municipality.
- If the product has been dropped, check for any abnormalities such as leakage before using it again.

How to Use

Freeze the product completely in the freezer before use. (Approximate freezing time: 4 to 8 hours)

If the product is not sufficiently frozen, it will not provide the required cooling effect.

[Precautions for Use]

To ensure the product performs appropriately, observe the following points:

- If the temperature inside the freezer does not reach -20°C / -4°F, the product may not freeze.
- If the product does not freeze sufficiently even when the freezer temperature is set to the lowest setting, remove as many items from the freezer as possible and place the product near the cold air outlet.
- The time required for the product to freeze completely is provided as a guideline only. The freezing process may take longer depending on the freezer performance and usage conditions.
- Wash the product thoroughly before freezing and after use, then use or store it.
- Wipe off any moisture on the product before placing it in a freezer. Otherwise, it may affect the freezing time.
- If the product is frozen while stacked or in contact with other ice packs or unfrozen food items, it may not freeze properly, which may affect its performance. Freeze the product without stacking.
- Do not allow the product to come into direct contact with raw food.

Warranty

- The performance of this product may deteriorate depending on the frequency of use and storage conditions. If it no longer provides sufficient cooling performance, we recommend replacing it with a new product.
- Snow Peak has taken all possible measures to ensure every product is durable and functions correctly. If you find any product defects, please contact the retailer where you purchased the product or Snow Peak Customer Service. If there are apparent defects in the product's manufacturing, the defective product will be repaired or exchanged free of charge. In other cases, Snow Peak will repair the product for an appropriate fee. Snow Peak will not repair the product for any damage that occurred due to the following:

1. Material deterioration caused by age
2. Damage caused by modifications or rough handling
3. Damage caused by inappropriate use not mentioned in the instruction manual
4. Damage caused by unexpected accidents
5. Any damage other than defects in the manufacturing process
6. Damage caused by dust or rust
7. Damage and defects caused by dismantling the product
8. Damage and defects caused by dropping, jolting or other shocks
9. Deterioration or failure of parts due to friction
10. Damage caused by the use of the product in combination with another manufacturer's products

Snow Peak USA, Inc.

404 NW 23rd Avenue, Portland, Oregon 97210, USA
Tel. +1 (888) 424-4916 / Instagram. @snowpeakusa
Email. info@snowpeak.com / www.snowpeak.com

Snow Peak, Inc.

456, Nakanohara, Sanjo-Shi, Niigata 955-0147 Japan
Tel. +81 256-46-5858 / Fax. +81 256-46-5860
www.snowpeak.co.jp