


FES-067-BK フォールディングシェルフメタルトップ ブラック

この度は、スノーピーク製品をお買い上げいただき、誠にありがとうございます。本製品は、組立式の棚台です。安全にご使用いただくためにも下記の取扱説明書をよく読んでからご使用ください。また、読み終わった後も大切に保管してください。説明内容で理解出来ない点及び製品に不具合が確認された際には直ちに使用を中止しご購入いただきました販売店様もしくは弊社ユーザーサービスまでお問い合わせください。

セット内容 (各部の名称)



取扱説明書 (本書)

スペック

- 材質:天板:ステンレス(耐熱塗装)、竹集成材、
脚:アルミニウム合金(アルマイト加工)
- 本体サイズ:846×340×397mm
- 天板サイズ:846×340mm
- 収納サイズ:846×470mm
- 重量:4.8kg

安全上の注意事項 ご使用の前によく読んで予測される事故を回避し安全にご使用ください。

⚠ 危険 明らかに生命に関わる重大な事故が予測される行為を示します。

●テーブルの上に乳幼児や小さいお子様を寝かせたり、座らせたりするのは危険ですので絶対にしないでください。●焚火や燃焼器具などの熱源から遠ざけてご使用ください。製品が熱くなり、ヤケドのおそれがあります。●本製品の天板上で加熱した鍋を置いたり、燃焼器具をご使用になる際は、天板上に他のガスカートリッジを使

用する製品や、ガスカートリッジ本体を絶対に置かないでください。ガスカートリッジが熱せられ、爆発や火災などの重大な事故につながるおそれがあり、大変危険です。

⚠ 警告 取扱いを誤った場合、使用者が死亡または重傷を負う可能性があることを示します。

●ご使用前に本製品を点検し、各部に異常がないことを確認してください。異常が発見された場合は、直ちに使用を中止しお買い求めいただいた販売店様、または弊社ユーザーサービスに点検または修理を依頼してください。●本製品と併用する各製品の取扱説明書をよく読んでからご使用ください。●天板に脚が確実にセットされていることを確認してからご使用ください。確実にセットされていないと、使用時にジョイント部が破損したり、天板が脱落して大変危険です。●天板にものを載せたまま本製品を移動しないでください。思わぬ事故の原因となります。●地盤のしっかりした平坦な場所を選び、凹凸のある場所や傾斜地で使用しないでください。●直射日光の当たる場所では天板が非常に熱くなりヤケドのおそれがあります。天板に触れたり座る場合は、日


陰であっても表面温度を確かめてご利用ください。また、直射日光が当たる場所や夏場の車内の保管も同様にヤケドの危険があります。直射日光の当たる場所や夏場の車内での保管はしないでください。●天面で直接火を焚かないでください。思わぬ事故や製品の破損の原因となります。●本製品の天板は金属製のため、天面で電気機器(ポータブルのIHヒーターや炊飯器)を使用すると、漏電により感電する危険性があります。電気機器の多くは野外での使用を想定しておりません。漏電する可能性が高いので絶対に使用しないでください。●機能を損なったり、強度が低下しますので改造は絶対に行わないでください。改造品のアフターサービスはお受けできません。

⚠ 注意 ケガや本体破損、物品破損として拡大被害の原因となる行為を示します。


●本製品は、傷が付くと金属の素地が露出します。運搬や取扱いには注意してください。●ジョイント部に異物や汚れが付着しないように注意してください。組み立てに支障をきたす原因となります。●本製品は端部処理を施していますが、端部で指を切るなどの危険性がありますので、取扱いには十分注意してください。●使用状況によってサビが発生することがあります。●本製品の上で直接調理や作業を行わないでください。本製品の傷や変形につながるおそれがあります。●本製品は塗装仕上げのため、天板の上での引きずると、塗装表面が剥がれて対象物に色移りするおそれがあります。●熱したダッチオーブンや鍋等を天板に置くと、熱により天板の塗膜が変色・融解する可能性があります。また冬など製品の温度が低い状態の時に熱いものを置くとヒートショックで塗装が剥がれるおそれがあります。●雨に長時間さらされたり、長時間水分に接すると、竹部の塗装

の内部に水分が浸透し、シミや変色などの原因となります。●本製品は常設用ではありません。また、常時重量物を置くような環境下では天板がゆがむ原因となります。●本製品は屋外用です。フローリングやカーペットなどの上で使用するとう脚キャップの跡がのこることがあります。●運搬時にぶついたり、強い衝撃を与えると破損の原因となりますのでご注意ください。●金属製のヘラや硬い素材のタワシなどを用いて汚れを落とさないでください。傷や変形のおそれがあります。汚れを落とす際は「メンテナンス方法」をご参照ください。●本製品の竹部は使用状況や保管状況により、反りやゆがみ、割れが発生することがあります。特に暖房の熱が直接当たる場所や直射日光が当たる場所や夏場の車内に保管しないでください。●高温・多湿・急激な温度変化を避けて保管してください。


使用方法




天板の表を手前にして体の前に置き、脚セットを持ちます。この時ロゴを上します。
※逆向きでは組立てられません。



天板裏にあるジョイント用鍵穴の2つの穴に脚セットのジョイントピンのヘッド部を同時に挿入します。この時、上の大きな穴より挿入し、下にスライドさせます。



次に脚の曲がり部分を持ち、ジョイントピンのヘッド部の片側を鍵穴形状の穴に挿入します。1脚に矢印の方へ力をかけ2ジョイントピンのヘッド部を鍵穴形状の穴に挿入します。



3箇所のジョイントピンが確実に挿入されたことを確認し、③と同様にジョイントピンのヘッド部を鍵穴形状の穴に挿入します。この時、③で挿入したジョイントピンがはずれないように、脚と天板をしっかりと手で固定してください。

メンテナンスについて

●長期間ご使用しなかった製品を再度お使いになる際は、本製品を点検し各部に異常がないことを確認してください。異常が発見された場合は、直ちに使用を中止しお買い求めいただいた販売店様、または弊社ユーザーサービスに点検または修理を依頼してください。●軽い汚れや水分が付着した場合は、速やかに乾いた布で拭き取ってください。●本製品をメンテナンスする際は、切り傷のおそれがあるため、手袋などの保護具を着用してください。●塩分

(調味料等)やその他の薬品が付着した場合は、固く絞った布でよく拭き取り、十分に乾燥させてください。●メンテナンスの際は、酸性やアルカリ性の洗浄剤、有機溶剤を含んだものを使用しないでください。塗装剥がれやシミの原因になります。●使用後、保管する際には直射日光を避け、風通しの良い場所で保管してください。

品質保証について

お買い求めいただきました製品は万全を期していますが、万一不備な点がございましたら、お買い求めいただいた販売店様もしくは弊社または各製品に記載された連絡先にご相談ください。製造上の欠陥が原因の場合は無償で修理または交換させていただきます。その他の場合は適切な価格で修理させていただきます。修理、交換の判断は弊社の裁量によるものとさせていただきます。また、以下の場合は修理できない場合もありますので予めご了承ください。

- 1.素材の経年劣化による損害など商品の寿命
- 2.改造および粗雑な取扱いによる故障
- 3.取扱説明書で禁止されている取扱いによる故障
- 4.不測の事故による商品の故障

- 5.その他製造上の欠陥以外による製品の故障
- 6.ゴミやさびによる故障
- 7.分解したことによる不具合の発生または破損
- 8.落下やその他の衝撃による部品の変形や破損による不具合

- 9.摩擦によるパーツの変化及びそれによる故障
- 10.他社製品との組み合わせによる故障

修理について

●本格的な修理が必要な場合は、お買い求めになった販売店様または弊社ユーザーサービスまでお問い合わせください。●修理を依頼される場合は、必ず十分に乾燥させ、汚れをきれいに落としてください。●修理品には修理箇所がはっきりと解るように、必ずメモまたは荷札を付けてください。また破損時の状況をできるだけ詳しく書いたメモを添えてください。●修理品の運賃並びに修理費については以下のように規定させていただきます。

- 1.保証対象の場合:往復運賃並びに修理費は弊社にて負担いたします。
- 2.保証対象以外の場合:往復運賃並びに修理費は、お客様のご負担とさせていただきます。

不明な点やお気付きの点がございましたら、販売店様または弊社ユーザーサービスまでお問い合わせください。


スノーピークユーザーサービス
☎0120-010-660(9:00~17:00)
Email:userservice@snowpeak.co.jp

株式会社スノーピーク
〒955-0147 新潟県三条市中野原456
Tel. 0256-46-5858 / Fax. 0256-46-5860
www.snowpeak.co.jp


FES-067-BK Folding Metal Top Shelf in Black

Thank you for purchasing a Snow Peak product. This is a folding shelf designed for camping use. For safety, read the following instruction manual before use. Please keep it safe for future reference. Finally, if you find anything that you do not understand in the description or any problems with the product, please stop use immediately and contact the retailer or Snow Peak Customer Service.

Contents (Name of the Parts)



Tabletop



Legs



Instruction Manual
(This Manual)

Specifications

- Materials: Tabletop : Stainless Steel (Heat Resistant Coating), Laminated Bamboo, Legs : Aluminum Alloy (anodized)
- Size: 846×340×397mm / 33.3"×13.4"×15.6"(h)
- Tabletop Size: 846×340mm / 33.3"×13.4"
- Storage Size: 846×470mm / 33.3"×18.5"
- Weight: 4.8kg / 10.6 lbs

Safety Precautions: Before use, please read thoroughly to ensure safety and avoid accidents.

⚠ DANGER / Misuse could easily result in a serious accident or death.

●Never place infants or small children on the table, whether lying down or seated. This may result in serious injury. ●Keep the product away from open flames and other heat sources. The surface may become hot and cause burns. ●When placing heated cookware on the tabletop or using a burner, never

place any gas cartridges or products that use gas cartridges on the tabletop. Gas cartridges may overheat and explode, resulting in fire, serious injury, or death.

⚠ WARNING / Misuse could result in serious injury or death.

●Before use, inspect the product and confirm that there are no abnormalities in any parts. If any abnormality is found, discontinue use immediately and contact the retailer where you purchased the product or Snow Peak Customer Service for inspection or repair. ●Read the instruction manuals for all products used in conjunction with this product before use. ●Make sure the legs are securely attached to the tabletop before use. If not properly secured, the joints may be damaged or the tabletop may detach during use, resulting in serious injury. ●Do not move the product while items are placed on the tabletop. This may result in unexpected accidents or injury. ●Select a flat, solid ground location. Do not use this product on uneven or sloping ground. ●The tabletop may become extremely hot when exposed to direct


sunlight and may cause burns. Before touching or sitting on the tabletop, check the surface temperature, even when used in shaded areas. Do not store the product in direct sunlight or inside a vehicle during hot weather, as this may result in burns. ●Do not build a fire directly on the tabletop. This may result in accidents or product damage. ●The tabletop is made of metal. Using electrical appliances (such as portable IH heaters or rice cookers) on the tabletop may cause electric shock due to electrical leakage. Most electrical appliances are not designed for outdoor use. Never use such appliances on this product, as this may result in serious injury or death. ●Do not modify the product. Modification may impair functionality or reduce strength. After-sales service is not available for modified products.

⚠ CAUTION / Misuse could result in injury to the user and/or damage to property.

●Scratches may expose the bare metal surface. Handle and transport the product with care. ●Do not allow foreign objects or dirt to enter the joints. This may interfere with assembly or proper operation. ●Although the edges are treated, they may still be sharp. Handle with care to avoid cuts or injury. ●Rust may occur depending on usage and environmental conditions. ●Do not perform cooking or work directly on the tabletop. This may cause damage or deformation. ●As this product has a painted finish, dragging items across the tabletop may cause the coating to peel and transfer color to the object. ●Placing heated Dutch ovens, pots, or similar cookware on the tabletop may cause discoloration or melting of the coating due to heat. Additionally, placing hot items on the tabletop when the product is cold (such as in winter) may cause the coating to peel due to thermal shock. ●Prolonged exposure to rain or moisture may allow


water to penetrate the bamboo components, causing stains or discoloration. ●This product is not intended for permanent installation. Leaving heavy items on the tabletop for extended periods may cause warping. ●This product is intended for outdoor use. Using it on flooring or carpets may leave marks from the leg caps. ●Avoid impacts during transport. Dropping or subjecting the product to strong shocks may cause damage. ●Do not use metal scrapers or hard brushes to clean the product. This may cause scratches or deformation. Refer to the "Maintenance" section for proper cleaning methods. ●The bamboo components may warp, deform, or crack depending on usage and storage conditions. Do not store in locations exposed to direct heat, direct sunlight, or inside a vehicle during hot weather. ●Store in a cool, dry place away from high temperatures, high humidity, and rapid temperature changes.

Instructions for Use




Place the tabletop in front of you with the top surface facing you, and hold the leg set. Make sure the logo is facing up.

*The product cannot be assembled if oriented incorrectly.




Insert the heads of the joint pins on the leg set simultaneously into the two keyhole slots on the underside of the tabletop.

Insert them through the larger upper openings, then slide them downward into place.



Next, hold the bent portion of the leg, and insert the joint pin head on one side into the keyhole shaped hole. **1** Apply force to the leg in the direction indicated with the arrow, **2** and then insert the joint pin head into the keyhole-shaped hole.



Confirm that three joint pins are securely inserted. Then, following step **3**, insert the remaining joint pin head into the keyhole slot. Hold the leg and tabletop firmly during assembly to prevent the previously inserted joint pins from coming loose.

Maintenance

●Before using a product that has been in storage for a long time, check each part for abnormalities. If there are abnormalities, take the product to the retailer or contact Snow Peak Customer Service for inspection or repair. ●If light dirt or moisture gets on the product, wipe it off promptly with a dry cloth. ●When performing maintenance on this product, wear protective gloves to prevent cuts. ●If salt (such as

seasonings) or other chemicals come into contact with the product, wipe it thoroughly with a well-wrung cloth, then allow it to dry completely. ●Do not use acidic or alkaline cleaners or products containing organic solvents for maintenance. This may cause peeling, staining, or damage to the coating. ●After use, store the product in a well-ventilated area away from direct sunlight.

Warranty

Snow Peak has taken all possible measures to ensure every product is durable and functions correctly. If you find any product defects, please contact the retailer where you purchased the product or Snow Peak Customer Service. If there are apparent defects in the product's manufacturing, the defective product will be repaired or exchanged free of charge. In other cases, Snow Peak will repair the product for an appropriate fee. The decision to repair or replace the product will be at our discretion. Snow Peak will not repair the product for any damage that occurred due to the following.

1. Material deterioration caused by age
2. Damage caused by modifications or rough handling
3. Damage caused by inappropriate use not mentioned in the instruction manual
4. Damage caused by unexpected accidents
5. Any damage other than defects in the manufacturing process

6. Damage caused by dust or rust
7. Damage and defects caused by dismantling the product
8. Damage and defects caused by dropping, jolting or other shocks
9. Deterioration or failure of parts due to friction
10. Damage caused by the use of the product in combination with another manufacturer's products

Repair

●If professional repairs are required, please contact the retailer where you purchased the product or Snow Peak Customer Service. ●When you request repairs, please make sure that the product is dry and clean. ●Please attach a memo or a tag indicating the necessary repair and please write details of how and when the damage occurred. ●Transportation and repair costs are determined as follows.

1. Within warranty: The transportation cost (both ways) and repair cost will be covered by Snow Peak.
2. Outside warranty: The transportation cost (both ways) and repair cost will be covered by the customer.

Snow Peak USA, Inc.

404 NW 23rd Avenue, Portland, Oregon 97210, USA
Tel. +1 (888) 424-4916 / Instagram. @snowpeakusa
Email. info@snowpeak.com / www.snowpeak.com

Snow Peak, Inc.

456, Nakanohara, Sanjo-Shi, Niigata 955-0147 Japan
Tel. +81 256-46-5858 / Fax. +81 256-46-5860
www.snowpeak.co.jp