


FP-250 / FP-251 / FP-252 ソフトバケツ 25 / 14 / 12

この度は、スノーピーク製品をお買い上げいただき、誠にありがとうございます。本製品は、キャンプ用折りたたみバケツです。安全にご使用いただくためにも下記の取扱説明書をよく読んでからご使用ください。また、読み終わった後も大切に保管してください。説明内容で理解できない点及び製品に不具合が確認された際には直ちに使用を中止しご購入いただきました販売店様もしくは弊社ユーザーサービスまでお問い合わせください。

セット内容



FP-250



FP-251



FP-252



取扱説明書(本書)

スペック

FP-250 ソフトバケツ 25

- 材質:ポリエステル 両面TPUラミネート、ポリプロピレン、ポリアセタール
- サイズ:φ360×300(h)mm
- 収納サイズ:160×560×100(h)mm
- 重量:420g

FP-251 ソフトバケツ 14

- 材質:ポリエステル 両面TPUラミネート、ポリプロピレン
- サイズ:310×310×180(h)mm
- 収納サイズ:330×295×30(h)mm
- 重量:320g

FP-252 ソフトバケツ 12

- 材質:ポリエステル 両面TPUラミネート、ポリプロピレン、ポリアセタール
- サイズ:φ240×270(h)mm
- 収納サイズ:150×375×60(h)mm
- 重量:230g

安全上の注意事項 ご使用の前によく読んで予測される事故を回避し安全にご使用ください。

⚠ 危険 明らかに生命に関わる重大な事故が予測される行為を示します。

- 本製品を本来の目的以外で使用しないでください。●小さいお子様が製品を頭からかぶったり、製品本体に入らないようにしてください。窒息や思わぬ事故の原因となります。●乳幼児の手の届かないところで使用

- してください。思わぬ事故の原因となります。●ベツが入らないようにしてください。窒息や思わぬ事故の原因となります。

⚠ 警告 取扱いを誤った場合、使用者が死亡または重傷を負う可能性があることを示します。

- ご使用前に、本製品を点検し各部に異常がないことを確認してください。異常が発見された場合は、直ちに使用を中止しお買い求めいただいた販売店様、または弊社ユーザーサービスに点検または修理を依頼してください。●ピンなど割れやすいものを入れる場合は十分にご注意ください。製品内部でピンが割れると同梱しているものにガラスが刺さり、大変危険です。●本製品内に重たいものを入れすぎないでください。持ち上げて運

- 搬する際に転倒するおそれがあります。●焚火やガス機器など、熱源のそばに置いて使用しないでください。製品破損だけでなく、火災につながります。●ベルトを首からかけないでください。ベルトが他のものに引っかかり、窒息やケガの原因になります。


⚠ 注意 ケガや本体破損、物品破損として拡大損害の原因となる行為を示します。

- はじめてご使用になる際は中性洗剤で洗ってください。●本製品に先端がとがった硬いものを入れないでください。本製品に穴が開く原因となります。●重いものを入れすぎると、変形破損するおそれがあります。入れすぎにはご注意ください。●ドライアイスは使用しないでください。生地劣化や破損の原因となります。●車中最高温になる場所に放置しないでください。高温になり製品劣化や破損の原因となります。●濡れた場所に長時間放置しないでください。劣化や変色の原因となります。●濡れた状態で使用すると色移りするおそれがあります。●


- 中に入れるものの温度や周囲の環境によって、外側に結露が発生することがあります。水に弱いもの(紙類、電子機器、布製品など)は、周囲に置かないでください。●食べ物や飲料が製品に付着すると、色移りするおそれがあります。●素材の特徴上、折りたたみを繰り返すと跡が残ります。使用上には問題ございません。●本製品はやわらかい素材でできています。保管の際や車内に置く場合には硬いものや重たいものに圧迫され変形や破損のおそれがあります。十分ご注意ください。●持ち手やベルトを持って振り回したり、強く引っ張りすぎないでください。

使用方法(製品の組み立て方・折りたたみ方)


【FP-250 ソフトバケツ 25】



【FP-251 ソフトバケツ 14】



【FP-252 ソフトバケツ 12】



メンテナンスについて

- 長期間ご使用しなかった製品を再度お使いになる際は、本製品を点検し各部に異常がないことを確認してください。異常が発見された場合は、直ちに使用を中止しお買い求めいただいた販売店様、または弊社ユーザーサービスに点検または修理を依頼してください。●使用後は中性洗剤でスポンジの柔らかい面を使用して洗ってください。その後、乾いた布でよくふき取っていただき、乾燥させてください。洗濯やアイロンはしないでください。●濡れた状態で保管しないでください。カビや経年劣化を早める原因となります。●金属製のタワシなど、硬いもので擦らないでください。●保管は日の当たらない風通しのいい涼しい場所で保管してください。

品質保証について

お買い求めいただきました製品は万全を期していますが、万一不備な点がございましたら、お買い求めいただいた販売店様もしくは弊社または各製品に記載された連絡先にご相談ください。製造上の欠陥が原因の場合は無償で修理または交換させていただきます。その他の場合は適切な価格で修理させていただきます。修理、交換の判断は弊社の裁量によるものとさせていただきます。また、以下の場合は修理できない場合もありますので予めご了承ください。1.素材の経年劣化による損害など商品の寿命 / 2.改造および粗雑な取扱いによる故障 / 3.取扱説明書で禁止されている取扱いによる故障 / 4.不測の事故による商品の故障 / 5.その他製造上の欠陥以外による製品の故障 / 6.ゴミやさびによる故障 / 7.分解したことによる不具合の発生または破損 / 8.落下やその他の衝撃による部品の変形や破損による不具合 / 9.摩擦によるパーツの変化及びそれによる故障 / 10.他社製品との組み合わせによる故障

修理について

- 本格的な修理が必要な場合は、お買い求めになった販売店様または弊社ユーザーサービスまでお問い合わせください。●修理を依頼される場合は、必ず十分に乾燥させ、汚れをきれいに落としてください。●修理品には修理箇所がはっきりと解るように、必ずメモまたは荷札を付けてください。また破損時の状況をできるだけ詳しく書いたメモを添えてください。●修理品の運賃並びに修理費については以下のように規定させていただきます。1.保証対象の場合:往復運賃並びに修理費は弊社にて負担いたします。 / 2.保証対象以外の場合:往復運賃並びに修理費は、お客様のご負担とさせていただきます。

不明な点やお気付きの点がございましたら、販売店様または弊社ユーザーサービスまでお問い合わせください。

スノーピークユーザーサービス
☎0120-010-660(9:00~17:00)
Email:userservice@snowpeak.co.jp

株式会社スノーピーク
〒955-0147 新潟県三条市中野原456
Tel. 0256-46-5858 / Fax. 0256-46-5860
www.snowpeak.co.jp

FP-250 / FP-251 / FP-252 Soft Bucket 25 / 14 / 12

Thank you for purchasing a Snow Peak product. This product is a collapsible bucket for camping. For safety, read the following instruction manual before use. Please keep it safe for future reference. Finally, if you find anything that you do not understand in the description or any problems with the product, please stop use immediately and contact the retailer or Snow Peak Customer Service.

Set Contents



FP-250



FP-251



FP-252



Instruction Manual
(This Manual)

Specifications

FP-250 Soft Bucket 25

- Materials: Polyester TPU laminate on both sides, Polypropylene, POM
- Size: $\phi 360 \times 300$ (h)mm / dia 14.2"x11.8"(h)
- Storage size: 160x560x100(h)mm / 6.3"x22.0"x3.9"(h)
- Weight: 420g / 14.8 oz

FP-251 Soft Bucket 14

- Materials: Polyester TPU laminate on both sides, Polypropylene
- Size: 310x310x180(h)mm / 12.2"x12.2"x7.0"(h)
- Storage size: 330x295x30(h)mm / 13.0"x11.6"x1.2"(h)
- Weight: 320g / 11.3 oz

FP-252 Soft Bucket 12

- Materials: Polyester TPU laminate on both sides, Polypropylene, POM
- Size: $\phi 240 \times 270$ (h)mm / dia 9.4"x10.6"(h)
- Storage size: 150x375x60(h)mm / 5.9"x14.8"x2.4"(h)
- Weight: 230g / 8.1 oz

Safety Precautions: Before use, please read thoroughly to ensure safety and avoid accidents.

⚠ DANGER / Misuse could easily result in a serious accident or death.

- Do not use this product for any purpose other than its intended use. ●Please do not let small children place the product over their heads or climb in the product itself. This may cause suffocation and unexpected accidents. ●Please keep this product out of the reach of children to avoid unexpected accidents. ●Please do not allow pets to climb into this product to avoid unexpected accidents.

⚠ WARNING / Misuse could result in serious injury or death.


- Before using the product, check each part for abnormalities. If there are abnormalities, take the product to the dealer or Snow Peak Customer Service for inspection or repair. ●Please be cautious when using this product with breakable items like glass bottles. If the bottle breaks inside the product, the glass will stick to the package or other items in the product, which is very dangerous.
- Do not put too many heavy items in this product. It increases the risk of falling when carrying the product. ●Do not use the product near any heat sources such as open fires or gas appliances. It will not only damage the product but also lead to fire. ●Do not wear the belt around your neck. The belt may catch on other objects, causing choking or injury.

⚠ CAUTION / Misuse could result in injury to the user and/or damage to property.


- Wash with a mild detergent before using this product for the first time. ●Do not store anything hard with a sharp tip in this product, as holes may form. ●If you put too many heavy items in the container, it may be deformed and damaged. Please be mindful of the weight. ●Do not use dry ice in this product as it may cause the fabric to deteriorate or break. ●Do not leave the product in a car or other places subject to high temperatures. High temperature may cause deterioration or damage. ●Do not leave the product in a wet place for an extended period of time. Doing so may lead to deterioration or discoloration. ●If the product is used in a wet area or is left wet for long periods, there is a risk of color staining. ●Condensation may form on the outside depending on the temperature of the items placed inside, or the surrounding environment. Do not place items that are sensitive to moisture (such as paper, electronic devices, or fabric products) near the product. ●If food or drink adheres to the inside of the product, there is a risk of color staining. ●Due to the nature of the material, repeated folding will leave marks. There is no problem in use. ●This product is made of soft material. When storing the product or leaving it in a car, be cautious of pressure from hard or heavy objects, as it may cause deformation or damage. Please handle it with care. ●Do not swing it around by the handle or belt or pull it too hard.

How to use (How to assemble and fold the product)


【FP-250 Soft Bucket 25】



【FP-251 Soft Bucket 14】



【FP-252 Soft Bucket 12】



Maintenance

- Before using a product that has been in storage for a long time, check each part for abnormalities. If there are abnormalities, take the product to the retailer or contact Snow Peak Customer Service for inspection or repair. ●After use, wash with a neutral detergent using the soft side of a sponge. Afterward, wipe well with a dry cloth and let dry. Do not wash or iron. ●Do not store this product when it is wet, as mold may form. ●Do not rub with abrasive objects such as metal scrubbing brush. ●Store in a cool, well-ventilated place away from direct sunlight.

Warranty

Snow Peak has taken all possible measures to ensure every product is durable and functions correctly. If you find any product defects, please contact the retailer where you purchased the product or Snow Peak Customer Service. If there are apparent defects in the product's manufacturing, the defective product will be repaired or exchanged free of charge. In other cases, Snow Peak will repair the product for an appropriate fee. The decision to repair or replace the product will be at our discretion. Snow Peak will not repair the product for any damage that occurred due to the following: 1. Material deterioration caused by age. / 2. Damage caused by modifications or rough handling. / 3. Damage caused by inappropriate use not mentioned in the instruction manual. / 4. Damage caused by unexpected accidents. / 5. Any damage other than defects in the manufacturing process. / 6. Damage caused by dust or rust. / 7. Damage and defects caused by dismantling the product. / 8. Damage and defects caused by dropping, jolting or other shocks. / 9. Deterioration or failure of parts due to friction. / 10. Damage caused by the use of the product in combination with another manufacturer's products.

Repair

- If professional repairs are required, please contact the retailer where you purchased the product or Snow Peak Customer Service. ●When you request repairs, please make sure that the product is dry and clean. ●Please attach a memo or a tag indicating the necessary repair and please write details of how and when the damage occurred. ●Transportation and repair costs are determined as follows: 1. Within warranty: The transportation cost (both ways) and repair cost will be covered by Snow Peak. / 2. Outside warranty: The transportation cost (both ways) and repair cost will be covered by the customer.