

## TW-360 / TW-470 サーモタンブラー 360 / 470

この度は、スノーピーク製品をお買い上げいただき、誠にありがとうございます。本製品はステンレス真空タンブラーです。安全にご使用いただくためにも下記の取扱説明書をよく読んでからご使用ください。また、読み終わった後も大切に保管してください。説明内容で理解出来ない点及び製品に不具合が確認された際には直ちに使用を中止しご購入いただきました販売店様もしくは弊社ユーザーサービスまでお問い合わせください。

### スペック

品番	品名	材質	サイズ	重量(本体一つあたり)	容量
TW-360	サーモタンブラー360	本体/ステンレス※塗装品のみ(外側ポリエステル塗装)	φ84×112mm	150g	360ml
TW-470	サーモタンブラー470	ボトムカバー/ポリコーンゴム	φ84×150mm	225g	470ml

**安全上の注意事項** ご使用前によく読んで予測される事故を回避し安全にご使用ください。

**⚠ 警告** 取扱いを誤った場合、使用者が死亡または重症を負う可能性があることを示します。

●ご使用前に、本製品を点検し各部に異常がないことを確認してください。異常が発見された場合は、直ちに使用を中止しお買い求めいただいた販売店様、または弊社ユーザーサービス係に点検または修理を依頼してください。●ボトムカバーが装着されていない状態で使用しないでください。不安定になり転倒するおそれがあります。●お子さまが近くにいるときは、本製品から目を離さないでください。いたづらなどにより、思わぬ事故の原因になります。特に熱い飲み物が入っているときはケガやヤケドの原因となります。●直火には絶対にかけないでください。真空二重構造の内圧が上昇して、破裂するおそれがあり危険です。●火のそばなど、高温になる場所に置かないでください。変形や変色、ヤケドの原因になります。●熱い飲み物に使用する際には、ヤケドには十分注意してご使用ください。●本製品を自動車などの運転中には使わないでください。車内や衣類を汚す原因となります。また、運転者の場合、運転への注意が散漫になり、大変危険です。●冷凍庫には入れないでください。破損の原因になります。●電子レンジで加熱しないでください。火花が飛んで、ケガ、故障の原因になります。

**⚠ 注意** ケガや本体破損、物品破損として拡大被害の原因となる行為を示します。

●本体に強い衝撃を加えたり落下させると気密性が低下して保温性能が失われます。●初めてお使いになるときは、工程上の油分等が残っていることがありますのでよく洗ってから使用してください。●飲料などを入れたまま長期間放置しないでください。●5個以上積み重ねないでください。転倒のおそれがあり危険です。●積み重ねて保管／運搬する際は、強く押さえ込んだり製品同士を擦り合わせないでください。表面に傷がつくおそれがあります。

### メンテナンス方法

●普段のお手入れには柔らかいスポンジに中性洗剤をつけてよく洗ってください。金属製のたわしや磨き粉は使用しないでください。●本製品をお手入れする際は、底面のボトムカバーを必ず外してください。洗剤や水分が残留するおそれがあります。●本製品は食器洗浄機や乾燥機を使用しないでください。●洗った後は乾いた布で水分をよく拭き取り、乾燥させてください。

### 品質保証について

お買い求めいただきました製品は万全を期していますが、万一不備な点がございましたら、お買い求めいただいた販売店様もしくは弊社または各製品に記載された連絡先にご相談ください。製造上の欠陥が原因の場合は無償で修理または交換させていただきます。その他の場合は適切な価格で修理させていただきます。修理、交換の判断は弊社の裁量によるものとさせていただきます。また、以下の場合は修理できない場合もありますので予めご了承ください。1.素材の経年劣化による損害など商品の寿命 / 2.改造および粗雑な取扱いによる故障 / 3.取扱説明書で禁止されている取扱いによる故障 / 4.不測の事故による商品の故障 / 5.その他製造上の欠陥以外による製品の故障 / 6.ゴミやさびによる故障 / 7.分解したことによる不具合の発生または破損 / 8.落下やその他の衝撃による部品の変形や破損による不具合 / 9.摩擦によるパーツの変化及びそれによる故障 / 10.他社製品との組み合わせによる故障

不明な点やお気付きの点がございましたら、販売店様または弊社ユーザーサービスまでお問い合わせください。

**スノーピークユーザーサービス**  
☎0120-010-660 (9:00~17:00)  
Email:userservice@snowpeak.co.jp

株式会社スノーピーク  
〒955-0147 新潟県三条市中野原456  
Tel. 0256-46-5858 / Fax. 0256-46-5860  
www.snowpeak.co.jp

## TW-360 / TW-470 Thermo Tumbler 360 / 470

Thank you for your purchase of Snow Peak products. This product is a stainless-steel, vacuum-insulated tumbler. For safety, read the following instruction manual before use. Also, please keep it safe after you finish reading it. If you find anything that you do not understand in the description or if there is any problem with the product, please stop using it immediately and contact the dealer from whom you purchased it or our user service.

### Specification

Item No.	Item Name	Material	Tumbler Size	Weight(pc)	Capacity
TW-360	Thermo Tumbler 360	Tumbler/ Stainless Steel *Painted products only (Outer Polyester Coating), Bottom Cover/	φ84x112mm / dia. 3.3"x4.4"	150g / 5.3oz	360ml / 12fl oz
TW-470	Thermo Tumbler 470	Silicone Rubber	φ84x150mm / dia. 3.3"x5.9"	225g / 8oz	470ml / 16fl oz

**Safety Instructions:** Before use, please read thoroughly to ensure safety and avoid accidents.

#### **⚠ Warning / Misuse could result in serious injury or death to the user.**

- Before using this product, please inspect it and make sure that there is nothing wrong with each part. If any abnormality is found, stop using the product immediately and ask the dealer where you purchased it or our User Service Department to inspect or repair.
- Do not use the product when the Bottom Cover is not attached. It may become unstable and tip over.
- Keep an eye on the product when children are nearby. Mischief can cause unexpected accidents. It may cause injury or burns, especially when hot drinks are contained.
- Do not put this product on or close to an open flame. Doing so can increase the internal pressure of the vacuum-sealed, double-wall design, potentially causing it to burst.
- Do not place this product near a fire or in areas subject to high temperatures. Doing so may cause deformation, discoloration, or burns.
- When using this product for hot drinks, please be careful not to get burned.
- Do not use this product while driving a car. It may stain the inside of the car and clothing. Also, in the case of a driver, attention to driving is distracted, which is extremely dangerous.
- Do not put this product in the freezer. Otherwise, the product may be damaged.
- Do not heat in the microwave. Sparks may fly and cause injury or malfunction.

#### **⚠ Caution / Indicates actions which may lead to injury, damage to this product, or damage to other items.**

- Avoid strong impacts and do not drop the product. The impact of dropping could damage the vacuum-sealed insulation, reducing the cooling capabilities.
- When using this product for the first time, apply a mild detergent to a soft sponge, and wash well.
- Please do not leave drinks in this product for long periods of time.
- This product can be stacked. Do not stack more than 5 at a time, as the stack could tip over.
- Do not press down strongly or rub the products against each other when storing or transporting in a stack. Doing so may cause damage to the surface.

### How to Maintain

- For regular maintenance, please apply a mild detergent to the soft sponge and wash well. (Do not use a metal brush or polishing powder when washing. It may damage the surface.)
- Be sure to remove the bottom rubber cover when cleaning this product. Detergent and water may remain.
- Do not use a dishwasher or dryer for this product.
- After use, wash well and dry well in a well-ventilated shade.

### Warranty

The specifications of Snow Peak products are based on field testing and quality control to ensure the correct function and longevity of every product. If apparent defects in the manufacturing of the product are found, the defective product will be repaired or exchanged free of charge. Damages, as follows, are not covered under warranty. / 1. Material deterioration caused by age. / 2. Damage caused by modifications or rough handling. / 3. Damage caused by improper use not following the instruction manual. / 4. Damage caused by unexpected accidents. / 5. Damage not caused by defects in the manufacturing process. / 6. Damage caused by dust or rust. / 7. Damage or defects caused when dismantling the product. / 8. Damage and defects caused by dropping or other shocks to the product. / 9. Deterioration or failure of parts due to friction. / 10. Damage caused by the use of the product in combination with other maker's products.

#### Snow Peak USA, Inc.

404 NW 23rd Avenue, Portland, Oregon 97210, USA  
Tel. +1 (888) 424-4916 / Instagram. @snowpeakusa  
Email. info@snowpeak.com / www.snowpeak.com

#### Snow Peak, Inc.

456, Nakanohara, Sanjo-Shi, Niigata 955-0147 Japan  
Tel. +81 256-46-5858 / Fax. +81 256-46-5860  
www.snowpeak.co.jp

MADE IN CHINA