

This product is a lightweight,
easy-to-handle camping apron using
flame-retardant fabric.

難燃生地を使用した軽量で扱いやすいキャンプエプロン。
焚火や調理時に、火の粉や汚れから守ります。

Specification / スペック

- Material: 67% ARAMID, 33% COTTON
- Size: Length: 950mm / 37.4", Width: 690mm / 27.2"
- Weight: 200g / 7.1 oz
- 材質: アラミド67%、綿33%
- サイズ: 着丈 / 950mm、身幅 / 690mm
- 重量: 200g

不明な点やお気付きの点がございましたら、販売店様または弊社
ユーザーサービスまでお問い合わせください。

スノーピーク ☎ **0120-010-660** (9:00~17:00)
ユーザーサービス Email: userservice@snowpeak.co.jp

株式会社スノーピーク 〒955-0147 新潟県三条市中野原456
Tel. 0256-46-5858 / Fax. 0256-46-5860
www.snowpeak.co.jp

Snow Peak USA, Inc.
404 NW 23rd Avenue, Portland,
Oregon 97210, USA
Tel. +1 (888) 424-4916
Instagram. @snowpeakusa
Email. info@snowpeak.com
www.snowpeak.com



袋

MADE IN CHINA



TAKIBIDAI
30th Anniversary
Camper Apron

焚火台30周年 キャンパーズエプロン



UG-930 焚火台30周年 キャンパーズエプロン TAKIBIDAI 30th Anniversary Camper Apron

Safety Precautions

Before use, please read thoroughly to ensure safety and avoid accidents.

⚠ DANGER Misuse could easily result in a serious accident or death.

●Keep this product away from open flames and hot objects. The material this product is made from contains flame-retardant, however, it will carbonize or deform if exposed to high temperatures for a long period of time. ●Do not store flammable gases or fuel in the pockets or loops while cooking. Doing so may cause an explosion or fire.

⚠ WARNING Misuse could result in serious injury or death.

●Before using the product, check each part for abnormalities. If there are abnormalities, take the product to the dealer or Snow Peak Customer Service for inspection or repair. ●Be careful not to tighten the neck strap too tightly, and avoid catching it on other objects. Doing so may lead to suffocation or cause a fall.

⚠ CAUTION Misuse could result in injury to the user and/or damage to property.

●If you stand near a fire while wet from the rain or water, you may get burns from steam. ●Putting metal or sharp objects in the pockets may damage the fabric and stitching. ●This product has a loop for hanging small items. Use this to temporarily hang towels and other items. Do not hang heavy objects or fuel cans. Doing so may damage the fabric and stitching.

Maintenance

●Before using a product that has been in storage for a long time, check each part for abnormalities. If there are abnormalities, take the product to the retailer or contact Snow Peak Customer Service for inspection or repair. ●When washing the comforter, carefully read the label attached to it. ●After washing, reshape the product and hang it up to dry. Twisting it excessively may cause the stitching to deform and the threads to break. ●When storing, keep in a well-ventilated place away from high temperatures, humidity, and direct sunlight.

Instruction Manual / 取扱説明書 : Ver 1.00

安全上の注意事項

ご使用前によく読んで予測される事故を回避し安全にご使用ください。

⚠ 危険 明らかに生命に関わる重大な事故が予測される行為を示します。

●本製品を火炎や高温物に直接近づけないでください。難燃素材ですが、長時間の高温下では炭化・変形します。●調理時に可燃性ガスや燃料をポケットやループに収納しないでください。爆発・火災の原因となります。

⚠ 警告 取扱いを誤った場合、使用者が死亡または重傷を負う可能性があることを示します。

●ご使用前に本製品を点検し、各部に異常がないことを確認してください。異常が発見された場合は、直ちに使用を中止しお買い求めいただいた販売店様、または弊社ユーザーサービスに点検または修理を依頼してください。●首紐を首に強く締めつけたり、他のものに引っかからないよう注意してください。窒息や転倒事故のおそれがあります。

⚠ 注意 ケガや本体破損、物品破損として拡大損害の原因となる行為を示します。

●雨や水に濡れた状態で火の近くに立つと、蒸気熱によりヤケドを負うおそれがあります。●ポケット内に金属製・尖ったものを入れると、生地や縫製を傷つけるおそれがあります。●本製品には、小物を掛けるためのループが付いています。タオルなどを一時的に掛ける際にご注意ください。重い物や燃料缶などは掛けないでください。生地や縫製部が破損するおそれがあります。

メンテナンス

●長期間ご使用しなかった製品を再度お使いになる際は、本製品を点検し各部に異常がないことを確認してください。異常が発見された場合は、直ちに使用を中止しお買い求めいただいた販売店様、または弊社ユーザーサービスに点検または修理を依頼してください。●洗濯をする際は、本体に取り付けられた注意表示をよくお読みください。●洗濯後は形を整えて干してください。強くねじると縫製部の変形・糸切れの原因になります。●保管時は高温多湿・直射日光を避け、通気の良い場所で保管してください。